

HoverCam CenterStage KnoteStar:



Whiteboard

A multi-touch digital whiteboard space allowing for annotation, note-taking and drawing. Whiteboard features panning, pinch-to-zoom, and tab creation to expand working space.



Desktop Marker


An annotation tool that allows users to annotate over any live program or application including web browsers, live video, presentation, word documents, and more.

Whiteboard:


KnoteSter features a multi-touch enabled whiteboard space and with pinch-to-zoom, panning, and screenshot functionalities. Select between the single touch icon and multi-touch icon at the top left of the screen to allow for multiple points of contact. Create separate pages for separate sections and lessons. To create a new tab, click the (+) icon at the bottom right of the screen. Click a tab to view the contents of that tab.

ANNOTATION WHEEL

The Whiteboard functions through use of the Annotation Wheel. The Annotation Wheel is a tool that uses various functions to create text, drawing, scripting and more. **Click the center orange icon to open the annotation wheel, then again to close it.** The functions include:



1. Undo
2. Redo
3. Canvas Selection
4. Create Type
5. Create Shape
 - a. Empty Rectangle
 - b. Filled Rectangle
 - c. Empty Ellipse
 - d. Filled Ellipse
 - e. Line
 - f. Arrow
6. Draw Tool
 - a. Pen Selection
 - b. Pen Settings
7. Eraser Tool
 - a. Trash Entire Page
 - b. Trash Selection
 - c. Eraser



6b

NOTE: To open item 6b for color, transparency and thickness selection, press and hold any of the items in 6a or 5a-f

SAVING WHITEBOARDS

To add a new Page, press the (+) icon (1). To navigate left or right between tabs, use the left (2) and right (3) icons. To delete a page, press the (X) icon (4). To save a whiteboard for future use press the Save option (5). You can also take screen shots from this menu that save directly to the desktop.



To open a previous whiteboard, click the Open option (6) and choose from the saved items. To open whiteboard options, select the (...) icon (7). Whiteboard options include:



Import Image



Snapshot



Crop and Snapshot



Save As



Desktop Marker

INTRODUCTION

The desktop marker application allows you to annotate **over any open program** including presentations, web browsers, live video, and more. **The desktop marker utilizes the same functions as the whiteboard.** To access the desktop marker, select the desktop marker option on the Knotester Dashboard.



SNAPSHOTS & SCREEN CAPTURES

When using the Desktop Marker, you can also take snapshots and screen captures to save your on-screen annotations. To take a snapshot, select the Snapshot Tool (1) icon on your annotation wheel. Drag and drop the corners to select the desired area and click the green check to save. Snapshots are saved to the Archive Manager. To start a screen capture, select the Mic Icon (2). This will launch the lesson recorder app. Use the screen capture functions the same as you would the Lesson Recorder.

